


BSA and BSAT
Bellows Sealed Stop Valves
Installation and Maintenance Instructions



1. *General
safety information*
2. *General
product information*
3. *Installation*
4. *Commissioning*
5. *Operation*
6. *Maintenance*
7. *Spare parts*

--- *1. General safety information* ---

Safe operation of the unit can only be guaranteed if it is properly installed, commissioned and maintained by a qualified person (see Section 11 of the attached Supplementary Safety Information) in compliance with the operating instructions. General installation and safety instructions for pipeline and plant construction, as well as the proper use of tools and safety equipment must also be complied with.

Warning

The body/bonnet collar gaskets contain a thin stainless steel support ring which may cause physical injury if they are not handled and disposed of carefully.

Care must be taken when opening and closing the handwheel to prevent any possible injury to the hands from the locking screw.

Lifting

Although the bonnet and handwheel will support the weight of the valve, it is recommended the slings for lifting are positioned around the back of the pipe flanges on the main body.

Isolation

Consider whether closing isolating valves will put any other part of the system or personnel at risk. Dangers might include; isolation of vents and protective devices or alarms. Ensure isolation valves are turned off in a gradual way to avoid system shocks.

Pressure

Before attempting any maintenance consider what is or may have been in the pipeline. Ensure that any pressure is isolated and safely vented to atmospheric pressure before attempting to maintain the product, this is easily achieved by fitting Spirax Sarco depressurisation valves type DV (see separate literature for details). Do not assume that the system is depressurised even when a pressure gauge indicates zero.

Temperature

Allow time for temperature to normalise after isolation to avoid the danger of burns and consider whether protective clothing (including safety glasses) is required.

Disposal

The product is recyclable. No ecological hazard is anticipated with the disposal of this product providing due care is taken, EXCEPT:

R-PTFE

The soft sealing disc insert (soft sealing disc option only) is made of R-PTFE, therefore, any scrap or waste material containing this part must be disposed of as follows:

- R-PTFE waste parts can only be disposed of by approved methods, not incineration.
- Keep R-PTFE waste in a separate container, do not mix it with other rubbish, and consign it to a landfill site.

2. General product information

2.1 General description

A range of bellows sealed, in-line stop valves having flanged PN16, PN25 and PN40 connections for use on steam, gas, liquid, condensate and water systems.


Note: Throttling plugs, soft seats (up to DN100), balancing discs (DN125 and above) are available for certain applications.

Available options:

Material and type		Valve trim					Bellows	
		Standard flat disc	Throttling plug and locking device	Balancing disc	R-PTFE soft seat standard disc	R-PTFE soft seat throttling plug	Single ply	Twin ply
Cast iron	BSA1	●					●	
	BSA1T		●					●
	BSA1 RPTFE				●		●	
	BSA1T RPTFE					●		●
	BSA1B/D			●				●
SG iron	BSA2	PN16	●				●	
		PN25	●†					●
	BSA2T	PN16		●				●
		PN25		●				●
	BSA2 RPTFE	PN16			●		●	
	BSA2T RPTFE	PN16				●		●
		PN25				●		●
Cast steel	BSA2B/D			●				●
	BSA3		●†					●
	BSA3T			●				●
	BSA3 RPTFE				●			●
	BSA3T RPTFE					●		●
	BSA3B/D			●				●

† DN125 and above only.

Standards

The product fully complies with the requirements of the European Pressure Equipment Directive 97/23/EC and carries the  mark when so required.

Certification

The BSA1 and BSA1T is available with certification to EN 10204 2.2. The BSA2, BSA2T, BSA3 and BSA3T is available with certification to EN 10204 3.1.B. **Note:** All certification/inspection requirements must be stated at the time of order placement.

Note: For additional information see Technical Information Sheets, TI-P137-18 and TI-P137-19.




Fig. 1 BSAT shown

Stroke limiter for throttling versions




Fig. 2

The handwheel nut on the **BSA1T**, **BSA2T** and **BSA3T** has a threaded hole for provision of a stroke limiter. Customer to supply standard nuts and bolts as indicated in the table below.

Size	Hexagon bolt
DN15 - DN80	M8 x 50 mm
DN100 - DN150	M12 x 75 mm
DN200 - DN250	M12 x 100 mm

Optional gland flange assembly (BSA3 ANSI ½" - 4" only)




Fig. 3

Optional balancing disc assembly




Fig. 4

	25 bar ΔP DN125	
Used	17 bar ΔP DN150	6"
above	10 bar ΔP DN200	8"
	6 bar ΔP DN250	(BSA2 only)

Optional soft sealing disc




Fig. 5

2.2 Sizes and pipe connections

2.2.1 BSA1 and BSA1T

DN15, 20, 25, 32, 40, 50, 65, 80, 100, 125, 150 and 200

Flanged EN 1092 / ISO 7005 PN16 and JIS B 2210 / KS B 1511 10K

Face-to-face EN 558

2.2.2 BSA2 and BSA2T

DN15, 20, 25, 32, 40, 50, 65, 80, 100, 125, 150, 200 and 250* (*PN25 only)

Flanged EN 1092 / ISO 7005 PN16 and PN25

Face-to-face EN 558

2.2.3 BSA3 and BSA3T (DIN)

DN15, 20, 25, 32, 40, 50, 65, 80, 100, 125, 150 and 200

Flanged EN 1092 / ISO 7005 PN40 (DN15 - DN150)

Flanged EN 1092 / ISO 7005 PN25 (DN200)

Face-to-face EN 558

2.2.4 BSA3 and BSA3T (ANSI)

Size ½", ¾", 1", 1½", 2", 3", 4", 6"* and 8"* (*ANSI 300 only)

Flanged ANSI B 16.5 / BS 1560 Class 150 and 300 and JIS B 2210 / KS B 1511 20K

Face-to-face ANSI B 16.10

2.3 Product limitations

BSA1 and BSA1T see Section 2.4

BSA2 and BSA2T see Section 2.5


BSA3 and BSA3T (DIN) see Section 2.6


BSA3 and BSA3T (ANSI) see Section 2.7

Note: The maximum permissible differential pressure in throttling function for BSA_T valves:

DN15 - DN80	2.0 bar	(29.00 psi)
DN100 - DN125	1.5 bar	(21.75 psi)
DN150	1.0 bar	(14.50 psi)
DN200 - DN250	0.8 bar	(11.60 psi)

2.4 Product limitations - BSA1 and BSA1T



 The product must not be used in this region.


A - A Flanged JIS / KS 10K

B - B Flanged PN16


Body design conditions		PN16	JIS / KS 10K
PMA - Maximum allowable pressure		16 bar g (232 psi g)	14 bar g (203 psi g)
TMA - Maximum allowable temperature		300°C (572°F)	220°C (428°F)
PMO - Maximum operating pressure for saturated steam service		12.9 bar g (187.05 psi g)	11 bar g (159.5 psi g)
TMO - Maximum operating temperature	Soft seat	230°C (446°F)	220°C (428°F)
	Metal seat	300°C (572°F)	220°C (428°F)
Minimum operating temperature		-10°C (14°F)	-10°C (14°F)
ΔPMX - Maximum differential pressure		BSA1	Limited to the PMO
		BSA1T	See note in Section 2.3
Designed for a maximum cold hydraulic test pressure of:		24 bar g (348 psi g)	20 bar g (290 psi g)


2.5 Product limitations - BSA2 and BSA2T

PN16



PN25




 The product must not be used in this region.


Body design conditions		PN16	PN25
PMA - Maximum allowable pressure		16 bar g (232 psi g)	25 bar g (362.5 psi g)
TMA - Maximum allowable temperature		350°C (662°F)	350°C (662°F)
PMO - Maximum operating pressure for saturated steam service		14.7 bar g (213.15 psi g)	22.3 bar g (323.35 psi g)
TMO - Maximum operating temperature	Soft seat	230°C (446°F)	230°C (446°F)
	Metal seat	350°C (662°F)	350°C (662°F)
Minimum operating temperature		-10°C (14°F)	-10°C (14°F)
ΔPMX - Maximum differential pressure		BSA2	Limited to the PMO
		BSA2T	See note in Section 2.3
Designed for a maximum cold hydraulic test pressure of:		24 bar g (348 psi g)	38 bar g (551 psi g)


2.6 Product limitations - BSA3 and BSA3T (DIN)

PN25, DN200




PN40, DN15 - DN150




 The product must not be used in this region.

Body design conditions		PN25, DN200	PN40, DN15 - DN150
PMA - Maximum allowable pressure		25 bar g (362.5 psi g)	40 bar g (580 psi g)
TMA - Maximum allowable temperature		400°C (752°F)	400°C (752°F)
PMO - pressure for saturated steam service	Soft seat	23.2 bar g (336.4 psi g)	27 bar g (391.5 psi g)
	Metal seat	23.2 bar g (336.4 psi g)	36.1 bar g (523.45 psi g)
TMO - Maximum operating temperature	Soft seat	230°C (446°F)	230°C (446°F)
	Metal seat	400°C (752°F)	400°C (752°F)
Minimum operating temperature		-10°C (14°F)	-10°C (14°F)
ΔPMX - Maximum differential pressure			BSA3 Limited to the PMO
			BSA3T See note in Section 2.3
Designed for a maximum cold hydraulic test pressure of:		38 bar g (551 psi g)	60 bar g (870 psi g)

2.7 Product limitations - BSA3 and BSA3T (ANSI)



 The product must not be used in this region.

C - D Flanged ANSI 150

C - E Flanged JIS / KS 20K

C - F Flanged ANSI 300

Body design conditions		ANSI 150	ANSI 300	JIS/KS 20K
PMA - Maximum allowable pressure		51 bar g (739.5 psi g)	51 bar g (739.5 psi g)	51 bar g (739.5 psi g)
TMA - Maximum allowable temperature		425°C (797°F)	425°C (797°F)	425°C (797°F)
PMO - Maximum operating pressure for saturated steam service	Soft seat	14 bar g (203 psi g)	27 bar g (391.5 psi g)	27 bar g (391.5 psi g)
	Metal seat	14 bar g (203 psi g)	30.7 bar g (445.15 psi g)	41.6 bar g (603.2 psi g)
TMO - Maximum operating temperature	Soft seat	230°C (446°F)	230°C (446°F)	230°C (446°F)
	Metal seat	425°C (797°F)	425°C (797°F)	425°C (797°F)
Minimum operating temperature		0°C (32°F)	0°C (32°F)	0°C (32°F)
ΔPMX - Maximum differential pressure		BSA3 Limited to the PMO		
		BSA3T See note in Section 2.3		
Designed for a maximum cold hydraulic test pressure of:		31 bar g (449.5 psi g)	77 bar g (1116 psi g)	50 bar g (725 psi g)

3. Installation

Note: Before actioning any installation observe the 'Safety information' in Section 1.

Referring to the Installation and Maintenance Instructions, name-plate and Technical Information Sheet, check that the product is suitable for the intended installation:

- 3.1** Check materials, pressure and temperature and their maximum values. If the maximum operating limit of the product is lower than that of the system in which it is being fitted, ensure that a safety device is included in the system to prevent overpressurisation.
- 3.2** Remove the protective covers from all connections.
- 3.3** Install the valve in the direction of flow given by the arrow on the body. The preferred position is with the spindle vertical. The valve can be installed from the vertical to the horizontal plane (see Figure 7, page 11).
- 3.4 Important note:** When a balancing disc is installed, the valve body should be mounted with the upstream fluid flowing into the upper valve chamber first, so the fluid pressure acts on top of the balancing disc. This is opposite to normal installation. If a balancing disc is upgrading or replacing a standard disc, the original valve body must be turned around in the pipeline and permanently marked with a new flow arrow indicating the changed direction of flow.

Do not mount the valve upside down.

What is a balancing plug, how does it work and why use it?

- A balancing plug is a two stage on/off mechanism.
- (See Figure 6) The pre-lifting plug (A) acts as a pilot valve and is opened first, allowing the medium to pass through at a controlled rate. The differential pressure then reduces across the valve - allowing the main valve plug (B) to be easily lifted off its seat. To assist closing the valve the flowing medium must enter on the 'Bellows' side, this is the opposite to normal installation.
- This device is fitted in the first instance to allow easy closure of the larger valves. In normal flow conditions it is impossible on large valves and high differential pressure to close the valve. By reversing the flow and installing a pilot valve, this problem is overcome.




Fig. 6

Should the differential pressure exceed those listed against the respective sizes in the table below then please remember 'Balancing plugs' must be used in all the valves.

Size	Differential pressure (bar)
DN125	25.0
DN150	17.0
DN175	13.0
DN200	10.0
DN250	6.0

- 3.5** When installed on steam systems a suitable steam trap should be fitted immediately upstream of the isolation valve to drain condensate. This will ensure drainage of the pipe when the valve is closed, and will prevent damage of the valve due to waterhammer. The drain trap should be either a ball float (FT) or thermodynamic (TD) type. Correct condensate drainage of all upstream pipework is also vital.
- 3.6** Always open isolation valves slowly to avoid system shocks.
- 3.7 Note:** It is advisable that when work is being carried out downstream of a valve installation, double isolation (block and bleed) should be fitted. In addition when installed as the final valve in a pipeline, as a safety precaution, a blanking plate or blank flange must be fitted to the outlet flange of the valve.

4. Commissioning

After installation or maintenance ensure that the system is fully functioning. Carry out tests on any alarms or protective devices.

5. Operation

5.1 The bellows sealed isolation valve plays an important role in the conservation of energy by eliminating fugitive stem seal emissions.

5.2 The valve is operated manually by a handwheel. Special care must be taken to ensure that the movement is made in the correct direction.

To open the valve fully, it is recommended to turn the handwheel until the shaft is raised to the maximum position, indicated by the (+) on the bonnet, then turn the handwheel clockwise an $\frac{1}{8}$ to $\frac{1}{4}$ turn to remove any backlash. This is to prevent the possibility of attempting to force open a valve, which is already fully open, resulting in damage to the stem, bellows unit or other components. Spirax Sarco BSA valves are fitted with a position indicator which can be found on the stem, and should align with the (+) or (-) on the bonnet support pillars. (+ = fully open / - = fully closed).

5.3 If valve 'keys' are used care must be taken not to use excessive force when opening or closing the valve.

5.4 BSAT valves are fitted with a throttling valve plug to allow close control when opening the valve. The number of turns open will affect the flowrate through the valve.

Once correct flowrate is obtained ensure the locking screw and stroke limiter (see Fig. 8, page 12) are tightened. This will minimise any vibration. The effect of valve opening for each valve size can be seen in the chart, page 12.




Fig. 7 **Incorrect installation**

Correct installation

BSAT flow data - The effect of valve opening for each valve size

Size DN	15	20	25	32	40	50	65	80	100	125	150	200	250
Hand-wheel rotations	K _v values for given handwheel rotations tested to EN 60534-2-3 Water at 20°C												
0	0	0	0	0	0	0	0	0	0	0	0	0	0
0.5	1.2	1.2	1.4	2.2	4.4	4.1	5.6	10.4	12.0	21	28	66	110
1	1.7	1.7	2.0	3.7	5.0	5.0	7.0	11.5	14.3	23	30	81	140
1.5	2.7	2.9	2.9	5.0	5.5	6.0	9.2	13.6	24.5	26	33	97	150
2	3.6	4.0	4.6	7.9	7.6	7.2	11.6	16.3	34.1	42	46	111	165
2.5	4.4	5.3	6.4	10.6	11.0	9.7	12.4	18.5	59.6	67	65	149	190
3	5.4	6.6	8.5	13.8	14.7	14.1	13.0	21.1	86.2	94	90	199	225
4			10.6	17.0	22.6	24.4	25.2	24.5	123.0	140	152	302	330
4.5			11.2	18.3	24.4	29.4	32.5	29.0	139.0	181	177	355	451
5			11.9	19.6	27.2	37.0	43.6	39.1	164.1	185	216	403	460
6					28.9	46.2	60.2	61.0	179.0	220	264	455	600
6.5					29.1	47.0	63.0	69.0	186.0	230	288	480	641
6.7					29.3	47.2	64.3	73.0		235	293	487	656
7							65.9	78.0		241	305	495	678
8							71.2	90.0		259	337	507	738
8.5							74.6	92.0			348	522	760
9.5								99.0			369		793
10								101.6					805
10.7													827

Stroke limiter for throttling versions

The handwheel nut on the **BSA1T**, **BSA2T** and **BSA3T** has a threaded hole for the provision of a stroke limiter. Customer to supply standard nuts and bolts as indicated in the table below:

Size	Hexagon bolt
DN15 - DN80	M8 x 50 mm
DN100 - DN150	M12 x 75 mm
DN200 - DN250	M12 x 100 mm

Note: The maximum permissible differential pressure in throttling function:

DN15 - DN80	2.0 bar
DN100 - DN125	1.5 bar
DN150	1.0 bar
DN200 - DN250	0.8 bar




Fig. 8

6. Maintenance

All the internals of the bellows sealed valve can be replaced (See Section 7, Spare parts).

Note:

Before actioning any maintenance programme observe the data in Section 1 - 'Safety information'.

Warning

The body/bonnet collar gaskets (10a and 10b) contain a thin stainless steel support ring which may cause physical injury if they are not handled and disposed of carefully.

- 6.1** Before undertaking any maintenance on the valve, ensure that any pressure is isolated and safely vented to atmospheric pressure. The valve should then be allowed to cool. When reassembling, ensure that all joint faces are clean.




Fig. 9

6.2 How to fit the body/bonnet gaskets

This can be carried out whilst the valve is connected in the pipeline. Remove the valve bonnet (2) from the body (1) by unscrewing bonnet studs/nuts (9). The body gasket (10b) is now visible and can quickly be replaced. Ensure the gasket face in the body (1) is clean before fitting a replacement.

To replace the second gasket (10a) which is situated between the bonnet (2) and the stainless steel bellows support collar, firstly remove the clip-on position indicator, remove the locking screw (BSAT versions only). Rotate the handwheel (7) in a clockwise direction. This pushes the main stem (6) downwards and creates a gap between the bellows support collar and the bonnet (2). If the support collar remains attached to the bonnet (2), gently prise the collar away from the bonnet being careful not to damage the collar.

Do not allow the bellows to stretch as this can reduce the bellows life.


By continually rotating the handwheel (7) in a clockwise direction, the stem (6) can be unscrewed from the bonnet bush. When the stem (6) is disconnected from the bonnet bush, unscrew the gland nut (unbolt the gland flange if fitted) and remove both this and the gland washer (or gland follower if fitted). Keep these parts safe as they are not supplied as spares. The stem / bellows assembly (6, 5) can now be withdrawn out of the bonnet (2). The second bellows collar gasket (10a) can now be replaced - ensuring both the bellows support collar surface and bonnet surface are clean and the gasket is accurately located. Before the stem / bellows assembly (6, 5) is reassembled into the bonnet (2), the stem packing ring (8) should be replaced (see Section 6.3).

6.3 How to fit the stem packing

By following through Section 6.2 it is now possible to replace the stem packing ring (8). Two of these rings are provided in the spares kit but only one is required. Ensure all of the old stem packing material is removed from the bonnet cavity and all locating surfaces are clean. Valve assembly is the opposite to removal - remembering to fit a bellows collar gasket between the collar and the valve bonnet. Ensure the solid stem pin (which is pressed into the stem) is aligned with the slot inside the bonnet. Before screwing the end of the stem into the bonnet bush remember to fit a new stem packing ring (8), the original gland washer (or gland follower) and gland nut (or gland flange) over the stem. **Do not allow the stem thread to damage the inner surface of the gland packing ring.** Carefully slide the new packing ring down the stem into the cavity and slide the original gland washer (or gland follower if fitted) on top of the packing ring. Remember to tighten the gland packing ring after the valve has been fully assembled.

6.4 How to fit the stem and bellows assembly

By following through Section 6.2 it is now possible to fit a new stem / bellows assembly (6, 5). Fitting this is opposite to removal - remembering to fit a bellows collar gasket (10a) between the bellows support collar and valve bonnet (2). Ensure the bellows collar gasket (10a) is accurately located. Before fitting the new stem / bellows assembly (6, 5) into the bonnet (2), apply a small amount of lubricating compound such as Gulf Sovereign LC grease to the end of the stem pin (which is pressed into the stem). Ensure the stem pin is aligned with the slot inside the bonnet. Carefully slide the stem up through the bonnet. Before screwing the end of the stem into the bonnet bush remember to fit a new stem packing ring (8) (see Section 6.3), the original gland washer (or gland follower) and gland nut (or gland flange) over the stem (6). **Do not allow the stem thread to damage the inner surface of the gland packing ring.** Carefully slide the new packing ring down the stem into the cavity and slide the original gland washer (or gland follower if fitted) on top of the packing ring (8). Remember to tighten the gland packing ring after the valve has been fully assembled.



6.5 How to fit the disc

By following through Section 6.2 it is now possible to replace the valve's disc. To replace the disc (4) (or balancing disc assembly*) simply remove the old stem pin and replace the disc (4). Attach the new disc with the new stem pin (supplied). Where the disc (4) is attached using a retaining nut and collet arrangement, simply prise the crimped skirt away from the retaining nut and unscrew. Remove the collets remembering to save these and the retaining nut as they are not supplied as spares. Fitting is the opposite to removal but ensure the collets and threads are lightly greased with lubricating compound such as Molybdenum Sulphide.

If a new disc is being fitted then crimp the collet retaining nut securely across two corners by deforming the disc's thin metal skirt. If the original disc is being fitted then re-crimp using a fresh part of the skirt.

*Important note

When a balancing disc is installed, the valve body should be mounted with the upstream fluid flowing into the upper valve chamber first, so the fluid pressure acts on top of the balancing disc. This is opposite to normal installation. If a balancing disc is upgrading or replacing a standard disc, the original valve body must be turned around in the pipeline and permanently marked with a new flow arrow indicating the changed direction of flow. See Section 3.4 for additional information.

6.6 Final assembly

Ensure the bellows support collar and gaskets (10a, 10b) are accurately aligned with the bonnet (2) before final assembly into the body (1).


Tighten the bonnet bolts/nuts (9) evenly to the recommended tightening torque (See Table 1).


Handwheel

The handwheel (7) is not supplied as a spare part. However, to remove the handwheel unscrew the main handwheel nut in a **clockwise** direction.

Note: The thread in the handwheel nut is left handed, so it must be unscrewed in a clockwise direction. Place a suitable spanner (a detailed drawing is available from Spirax Sarco) across the flats of the bonnet bush (2) and unscrew the handwheel in the normal way. **Note:** the handwheel may be firmly secured on the bonnet bush (2). Refitting the handwheel is the opposite to removal. Apply Loctite 638 to the threads of the handwheel boss and tighten to 50 N m (36 lbf ft). Remember to tighten the handwheel nut to 40 N m (29 lbf ft) in an **anticlockwise** direction.

Table 1 Recommended bonnet tightening torques N m (lbf ft)

Size	 mm	BSA1 / BSA1T PN16 JIS/KS 10K	BSA2 / BSA2T PN16 / PN25	BSA3 / BSA3T	
				PN40	ANSI 150 / 300 JIS/KS 20K
DN15 - DN32	17 A/F	20 - 25 (15 - 18)	35 - 40 (26 - 29)	35 - 40 (26 - 29)	50 - 55 (36 - 40)
DN40 - DN65	19 A/F	40 - 45 (29 - 33)	55 - 60 (40 - 44)	55 - 60 (40 - 44)	85 - 90 (63 - 66)
DN80 - DN150	24 A/F	70 - 80 (51 - 59)	130 - 140 (95 - 103)	130 - 140 (95 - 103)	190 - 200 (140 - 147)
DN200	30 A/F	180 - 200 (132 - 147)	260 - 280 (191 - 206)	260 - 280 (191 - 206)	300 - 320 (220 - 235)
DN250	36 A/F	480 - 520 (352 - 382)			



7. Spare parts

The spare parts available are shown in heavy outline. Parts drawn in broken line are not supplied as spares.

Available spares

Body/bonnet gasket and stem packing	10a, 10b, 8 (2 off)
Stem and bellows assembly (state if BSA or BSAT)	6, 5
Disc (and optional disc where fitted) - state full description of the valve	4

How to order spares

Please note: for customer convenience spares are supplied in kits to ensure all the appropriate replacement parts are supplied to carry out a specific maintenance task. e.g. when a stem/bellows assembly is ordered, parts (**10a** and **10b**), (**8**) and (**6, 5**) will be included in the kit.

Always order spares by using the description given in 'Available spares' and state the size and type of stop valve.

Example: 1 - Body / bonnet gasket and stem packing for a DN15 Spirax Sarco BSA2 PN16 bellows sealed stop valve.

Note: The gaskets contain sharp metal reinforcement, please handle with care.
--




Fig. 12
BSAT shown

