


spirax /sarco

Capacity Charts for 600 Series and 900 Series Inverted Bucket Steam Traps


Canacities for the 600 Series



Note: Traps should be selected for the most appropriate working pressure differential and not on the basis of load.

For further technical information on this product see TI-P067-01.

Capacities for the 900 Series



Note: Traps should be selected for the most appropriate working pressure differential and not on the basis of load.

For further technical information on this product see TI-P067-02.